


StereoZoom 7 1.0X thru 7.0X Variable Power Pod, Cat. No. 31-27-01

Key	Description	Part No.
1	Tube	312701-438
2	Dust Cover	312701-047
3	Snap Ring	312701-437
4	Dust Seal	312701-496
5	Adapter (left)	312701-234
6	Adapter (right)	312701-325
7	not exploded	not exploded
8	2-64 x 1/16 Set Screw	312701-379ND
9	Eyepiece Ring	312701-236
10	Gasket	312701-356
11	6-32 x 1/4 Fillister Hd Screw	312701-436ND
12	Lower Housing	312701-510
13	Mounting Spring	312701-349
14	1/8 x 1/4 dia Washer	312701-351ND
15	1-40 x 1/4 Phillips Hd Screw	312701-308ND
16	6-32 x 1/2 Fillister Hd Screw	312701-400ND
17	Cover Plate	312701-393
18	F-332 Washer	90008-463
19	Knob	312701-507
20	Tru-Arc 5133-25	312695-111ND
21	F-310 Washer	90008-378
22	4-40 x 1/4 Set Screw	312701-485
23	Gear & Shaft Assy	312701-408
24	Name Plate	312701-509



NOTE: IT IS RECOMMENDED THAT PARTS NOT NUMBERED BE REPLACED AND INSTALLED AT THE FACTORY SHOULD THE NEED EVER ARISE.