


# StereoZoom 7 1.0X thru 7.0X Variable Power Pod, Cat. No. 31-27-01

Key	Description	Part No.
1	Tube	312701-438
2	Dust Cover	312701-047
3	Snap Ring	312701-437
4	Dust Seal	312701-496
5	Adapter (left)	312701-234
	Adapter (right)	312701-325
	not exploded	
6	2-64 x 1/16 Set Screw	312701-379ND
7	Eyepiece Ring	312701-235
8	Eyepiece Adjusting Ring	312701-236
9	Gasket	312701-356
10	6-32 x 1/4 Fillister Hd Screw	312701-436ND
11	Lower Housing	312701-510
12	Mounting Spring	312701-349
13	1/8 x 1/4 dia Washer	312701-351ND
14	1-40 x 1/4 Phillips Hd Screw	312701-308ND
15	6-32 x 1/2 Fillister Hd Screw	312701-400ND
16	Cover Plate	312701-393
17	F-332 Washer	90008-463
18	Knob	312701-507
19	Tru-Arc 5133-25	312695-111ND
20	F-310 Washer	90008-378
21	4-40 x 1/4 Set Screw	312701-485
22	Gear & Shaft Assy	312701-408
23	Name Plate	312701-509



**NOTE: IT IS RECOMMENDED THAT PARTS NOT NUMBERED BE REPLACED AND INSTALLED AT THE FACTORY SHOULD THE NEED EVER ARISE.**